

Installation instructions

1. Identify all components are present prior to installation.
2. Fit the waste body(1) and washer (2) into the basin
3. Fit the washer (3) underneath the basin as shown in the diagram, then secure by tightening the backnut (4)

Use a pure silicon sealant where necessary

4. Check all joints and connections for leaks.

1. Waste body x 1
2. Washer x 1
3. Washer x 1
4. Back nut x 1

