



\*When installing the diverter, position it so that the arrow on it labelled 'INLET' points away from the slider rail and the thread on the opposite side is screwed into the riser kit. The thread in which the arrow points to should then be attached to the shower valve with a hose.