

INSTALLATION INSTRUCTIONS

(FOR THE EXCLUSIVE USE OF THE PROFESSIONAL INSTALLER)


Important Information

Installation should be carried out by a qualified professional or other fully competent person and should be installed in accordance with the relevant British and European Standards (BS5449:1990, BS7593:1992, EN12828:2003 & EN12831:2003)

PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY BEFORE USING THE APPLIANCE.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised. Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The heater must not be located immediately below a socket-outlet.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- WARNING: In order to avoid overheating, do not cover the heater.
- Do not use this heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- This heater is filled with a precise quantity of special oil. Repairs requiring opening of the oil container are only to be made by the manufacturer or his service agent who should be contacted if there is an oil leak.(only for oil-filled radiator)

- When scrapping the heater, follow the regulations concerning the disposal of oil. Do not dispose of the heater in household waste and recycle the heater where local facilities exist for electrical goods and oil. (only for oil-filled radiator)



In order to avoid a hazard for very young children, this appliance should be installed so that the lowest heated rail is at least 600 mm above the floor. the towel rail is to be installed so that switches and other controls cannot be touched by a person in the bath or shower

PLEASE ENSURE THAT YOU WEAR ALL NECESSARY PERSONAL PROTECTIVE EQUIPMENT FOR YOUR SAFETY.

Please check that all components are present and that you are ENTIRELY happy with the size, design and finish BEFORE starting installation.

THIS TOWEL WARMER HAS BEEN PRE-FILLED AND ADJUSTED FOR ELECTRICAL STAND ALONE USE. NO FILLING IS REQUIRED; DO NOT REMOVE ANY OF THE SEALS AS THIS MIGHT CAUSE LEAKAGES AND VOID THE WARRANTY.

Pack Contents







1 x Electric Towel Warmer	4 x Bracket Front	4 x Wall Screw
2 x Decorative cover cap	4 x Bracket Cover	4 x Washer
4 x Bracket Base	4 x Wall Plug	4 x Bracket Screw
4 x Bracket Ttem	4 x Mini Screw	

FITTING THE TOWEL RAIL ON TO THE WALL

STEP 1

Select your desired mounting position and check that the wall is sufficiently strong enough to hold the weight of the towel warmer filled with water. Mark your preferred bracket positions on the wall and drill holes as necessary for the fixings that you are using. The Wall Plugs supplied are only suitable for solid walls. Please note: If the wall is other than a solid construction other means of fixings will be required.



<p>STEP 2. Screw the Bracket Base to the wall using the Wall Screws and Washers provided.</p>	
<p>STEP 3. Loosely fit the Bracket Stems to the towel warmer with the Bracket Fronts and Bracket Screws.</p>	
<p>STEP 4. Align the Bracket Stems with the Bracket Bases and push the towel warmer back into position.</p>	
<p>STEP 5. Tighten the Bracket Screws with a screwdriver.</p>	
<p>STEP 6. Insert the Mini Screws into the Bracket Bases and tighten with a screwdriver to lock bracket into position.</p>	
<p>STEP 7. Push the Cover Caps into position on the Bracket Fronts. Finally put decorative covers onto air vent and blanking plug.</p>	

CONNECTING THE TOWEL RAIL

Always switch off the electricity supply at the mains during installation.

The power supply to the towel dryer must be protected, in accordance with applicable standards, by a 30mA differential circuit-breaker, 16A rated. Before carrying out any connection tasks, cut off the power supply to the electronic regulator using the circuit breaker or the protection fuse in the power supply circuit.

For the wire connection, please also add below sentences:

You need to follow the below requirements when you install your heater:

IP24 THIS PRODUCT IS SUITABLE FOR BATHROOMS (DRY) OUTSIDE ZONES ONLY

Means for disconnection having a contact separation in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.

Warning: you need to connect the 3 wires of the supply cable to a connection block ensuring the mains polarity is followed as below:

IMPORTANT: The wires in the mains lead are coloured in accordance with the following code:

Blue – Neutral

Brown – Live

Green/Yellow – Earth

The blue wire must be connected to the terminal marked with an N or coloured black.

The brown wire must be connected to the terminal marked with an L or coloured red.

The green/yellow wire must be connected to the earthing terminal which is marked with an E or with the earth symbol .

WARNING: Never connect live or neutral wires to the earth terminal.

All fittings must be installed by a competent person in accordance with the current IEE Wiring Regulations (Bs7671). If in doubt, consult a qualified electrician.

This product is suitable for use in living areas, and Bathroom dry (Outside) Zones only (see diagram below and current IEE Wiring Regulations for details). It is not suitable for Bathroom Zones 0, 1. If being fitted in a bathroom a 30mA RCD must be used. This appliance does not come fitted/supplied with a fused plug. **DO NOT** wire/fit a plug to this appliance. The appliance must be wired to a fused fixed spur, which is fitted with a 13Amp fuse.


Always refer to the Reference Drawing for Bathroom Installation.

Note: the below drawing is for reference only.

We suggest you to contact a professional electrician for any help.

* Full details can be found in the current IEE Wiring Regulations (Bs7671)

Please NOTE: (as per the illustrations below) that the heating element must always be located at the bottom of the rail (eitherside). NEVER from the Top.



WARNINGS

according to new standard, all the safety sentences must be on the beginning of the IM and the height of the letter **MUST** at least 3mm (suggest keep 3.5mm height).

Please also add below sentences as standard required:

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- WARNING: In order to avoid a hazard for very young children, this appliance should be installed so that the lowest heated rail is at least 600 mm above the floor.
- Means for disconnection having a contact separation in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.

CARE AND MAINTENANCE

- . Regular cleaning with a soft cloth will keep the surfaces of your tower warmer looking new.
- . Soapy water can be used to remove stubborn stains and then buff dry with a soft cloth.
- . Do not use abrasive or chemical cleaners to clean your towel warmer as these will damage the surface finish over time.

DISPOSAL



This appliance is NOT an ordinary domestic refuse. It must be disposed of through the appropriate recollection centres to be recycled. In case of replacement it can be sent back to your distributor.

This handing of the product's end of life will allow us to preserve our environment and curb the consumption of natural resources. This symbol applied on the product, indicates the obligation to consign it to a special recollection centre to be disposed of in accordance with European Directive WEEE 2012/19/EU guideline. The manufacturer reserves the right to modify the product without previous notice for technical or construction improvements.

This towel warmer is warranted for a period of 1 year against manufacturing defects only.